

www.raisecom.com

Commands of Transparent Transmission and Forward-3



CONTENTS



Chapter 1	Commands of Transparenting Transmission and Forward	1
1.1	dlf-forwarding	1
1.2	show dlf-forwarding	1

Chapter 1 Commands of Transparenting Transmission and Forward

1.1 dlf-forwarding

[Function]

Enable or disable DLF forwarding.

[Command Format]

dlf-forwarding {*enable* | *disable*} [*schedule-list list-no*]

[Parameter]

enable: forward DLF message;

disable: do not forward DLF message;

schedule-list: Set the starting time, ending time and time interval of the schedule;

list-no: schedule list range is <0-99>.

[Default]

enable

[Command Modes]

Global configuration mode; Privileged user

[Executing Command Instruction]

Only the privileged user with priority 15 can use this command.

[Explanation of command execution echo]

Set successfully

Set unsuccessfully

[Example]

Forward DLF message:

Raisecom(config)# **dlf-forwarding** *enable*

[Related commands]

Commands	Description
show dlf-forwarding	Show DLF forwarding status.

1.2 show dlf-forwarding

[Function]

Show whether to forward DLF message.

show dlf-forwarding**[Command Modes]**

Privileged EXEC; privileged user.

[Explanation of command execution echo]

DLF-forwarding: Enable

[Example]

Raisecom# **show dlf-forwarding**

[Related commands]

Commands	Description
dlf-forwarding {enable disable}	Forward or terminate DLF packet locally.



北京瑞斯康达科技发展有限公司
RAISECOM TECHNOLOGY CO.,LTD.

Address: 2nd Floor, South Building of Rainbow Plaza, No.11 Shangdi Information Road,
Haidian District, Beijing Postcode: 100085 Tel: +86-10-82883305 Fax: +86-10-82883056
Email: export@raisecom.com <http://www.raisecom.com>