

[www.raisecom.com](http://www.raisecom.com)

**MST Function Commands-1**



# CONTENTS



Chapter 1	MST Function Commands	1
1.1	debug	1

## Chapter 1 MST Function Commands

### 1.1 debug

#### [Function]

Use **debug** command to turn on modular debugging switch, **no** command to turn the switch off.

#### [Command Format]

[ **no** ] **debug** (*all / system / ospf / rip / gvrp / igmp-snooping / mvr / cli / driver / dhcp / snmp / stp / lacp / rcmp / rndp / rtdp / radius / dot1x / qos / rmon / sntp / telnet / arp / ip / config*)

#### [Parameter]

*all*: debug all functions

*arp*: arp debug

*cli*: cli debug

*config*: system config information

*dhcp*: dhcp debug

*dot1x*: dot1x debug

*driver*: driver debug

*gvrp*: gvrp debug

*igmp-snooping*: igmp-snooping debug

*ip*: ip debug

*lacp*: lacp debug

*ospf*: ospf debug

*qos*: qos debug

*radius*: radius debug

*rcmp*: rcmp debug

*rip*: rip debug

*rmon*: rmon debug

*rndp*: rndp debug

*rtdp*: rtdp debug

*snmp*: snmp debug

*sntp*: sntp debug

*stp*: stp debug

*system*: system debug

*telnet*: telnet debug

#### [Default]

Config module is enabled

System module is enabled

Others debug functions are disabled

#### [Command Modes]

Privileged EXEC, Privileged user

#### [Executing Command Instruction]

Use this command to enable some or all module **debug** functions. **All** indicates all modules, **config** module indicates it can be record in flash file system.

#### [Example]

Raisecom#**debug all**

#### [Related commands]

Commands	Description
<b>logging</b>	Configure system log



**北京瑞斯康达科技发展有限公司**  
**RAISECOM TECHNOLOGY CO.,LTD.**

Address: 2<sup>nd</sup> Floor, South Building of Rainbow Plaza, No.11 Shangdi Information Road,  
Haidian District, Beijing Postcode: 100085 Tel: +86-10-82883305 Fax: +86-10-82883056  
Email: export@raisecom.com <http://www.raisecom.com>