

www.raisecom.com

Commands of Interface Configuration-2

CONTENTS



Chapter 1	Commands of MAC Address Management	1
1.1	FLOWCONTROL	1

Chapter 1 Commands of Interface Configuraiton

1.1 flowcontrol

[Function]

Enable or disable the flow control function at the physical port.

[Command Format]

flowcontrol {on / off} [schedule-list list-no]

[Parameter]

on: Enable flow control function;

off: Disable flow control function;

schedule-list: set the starting time, ending time and time interval of periodical execution;

list-no: schedule list number range from <0-99>.

[Default]

The flow control function is disabled at physical port by default.

[Command Modes]

Physical ports/range configuration mode; privileged user

[Executing Command Instruction]

Only users with priority 15 can use this command, flow control configuration is unsuccessful when sub-card is unavailable.

[Explanation of command execution echo]

Set successfully

Port X set unsuccessfully

Port x is unavailable!

[Example]

Enable the flow control function of physical port:

Raisecom(config-port)# **flowcontrol on**

Disable the flow control function of physical port:

Raisecom(config-port)# **flowcontrol off**

[Related commands]

Commands	Description
show inter port port-list	Show the port configuration information.



北京瑞斯康达科技发展有限公司
RAISECOM TECHNOLOGY CO.,LTD.

Address: 2nd Floor, South Building of Rainbow Plaza, No.11 Shangdi Information Road,
Haidian District, Beijing Postcode: 100085 Tel: +86-10-82883305 Fax: +86-10-82883056
Email: export@raisecom.com <http://www.raisecom.com>