

www.raisecom.com

SNMP Commands-2



CONTENTS



Chapter 1	SNMP Commands	1
1.1	show snmp access	1

Chapter 1 SNMP Commands

1.1 show snmp access

[Function]

Enable/disable transceiver modular parameter abnormal trap.

[Command Format]

snmp trap transceiver {*enable/disable*}

[Parameter]

enable: transceiver traps enable;

disable: transceiver traps disable.

[Default]

enable

[Command Modes]

Global configuration mode; privileged user

[Executing Command Instruction]

Use this command to enable/disable send optical modular parameter abnormal trap.

[Command Executing Echo]

Set successfully.

[Example]

Disable send optical modular parameter abnormal trap:

Raisecom(config)#**snmp trap transceiver** *disable*

[Related commands]

Commands	Description
show interface transceiver detail	Show details information of digital diagnosis.



北京瑞斯康达科技发展有限公司
RAISECOM TECHNOLOGY CO.,LTD.

Address: 2nd Floor, South Building of Rainbow Plaza, No.11 Shangdi Information Road,
Haidian District, Beijing Postcode: 100085 Tel: +86-10-82883305 Fax: +86-10-82883056
Email: export@raisecom.com <http://www.raisecom.com>