

[www.raisecom.com](http://www.raisecom.com)

## **Trunk Group Commands-2**



# CONTENTS



**Chapter 1    Trunk Group Commands----- 1**  
    **1.1 trunk loading-sharing ticket-generation-algorithm -----1**

## Chapter 1 Trunk Group Commands

### 1.1 trunk loading-sharing ticket-generation-algorithm

#### [Function]

Set loading-sharing ticket algorithm of the trunk.

#### [Command Format]

**[no] trunk loading-sharing ticket-generation-algorithm**{*crc*|*direct-map*}

#### [Parameter]

*crc*: CRC value of MAC address;

*direct-map*: direct mapping value.

#### [Command Modes]

Global configuration mode

#### [Executing Command Instruction]

This command is used to set load-sharing ticket algorithm.

#### [Explanation of command execution echo]

*Set successfully*

*Set unsuccessfully !*

#### [Example]

Set load-sharing ticket algorithm based on CRC:

Raisecom# **trunk loading-sharing ticket-generation-algorithm** *crc*

#### [Related commands]

Commands	Description
<b>show trunk</b>	Show trunk information.



**北京瑞斯康达科技发展有限公司**  
**RAISECOM TECHNOLOGY CO.,LTD.**

Address: 2<sup>nd</sup> Floor, South Building of Rainbow Plaza, No.11 Shangdi Information Road,  
Haidian District, Beijing Postcode: 100085 Tel: +86-10-82883305 Fax: +86-10-82883056  
Email: [export@raisecom.com](mailto:export@raisecom.com) <http://www.raisecom.com>