

www.raisecom.com

Commands of Interface Configuration-3

CONTENTS



Chapter 1	Commands of Interface Configuraiton	1
1.1	show interface port	1

Chapter 1 Commands of Interface Configuraiton

1.1 show interface port

[Function]

Show port information of remote device.

[Command Format]

show interface port

[Parameter]

port-list: port list.

[Command Modes]

Remote configuration mode; privileged user

[Executing Command Instruction]

Show remote device interface information, including port management status, operation status, speed and duplex and flow control enable/disable, in remote configuration mode. Remote device interface information will not be shown if remote device is unconnect or OAM link is not established.

[Explanation of command execution echo]

Raisecom(config-remote)#**show interface port**

Local Port: 12

Port	Admin	Operate	Speed/Duplex	Flowcontrol	Flowcontrol Set

line 1	enable	up(100M/full)	100M/full	off	disable
client 1	disable	down	auto	off	disable
client 2	disable	down	auto	off	disable
client 3	disable	down	auto	off	disable
client 4	enable	up(100M/full)	auto	off	disable

[Example]

Raisecom(config-port)# **show interface port**

[Related commands]

Commands	Description
shutdown	Enable/disable remote client port.
duplex {full half}	Configuring duplex for remote device.
speed (auto/10/100/1000)	Configuring speed for remote device.

flowcontrol <i>{on/off}</i>	Enable/disable remote client port flow control.
show interface port detail	Show detail information of remote device port.



北京瑞斯康达科技发展有限公司
RAISECOM TECHNOLOGY CO.,LTD.

Address: 2nd Floor, South Building of Rainbow Plaza, No.11 Shangdi Information Road,
Haidian District, Beijing Postcode: 100085 Tel: +86-10-82883305 Fax: +86-10-82883056
Email: export@raisecom.com <http://www.raisecom.com>