

www.raisecom.com

Telnet Commands-1

CONTENTS



Chapter 1	Telnet Commands	1
1.1	show telnet-server	1
1.2	telnet	1
1.3	telnet-server close	2
1.4	telnet-server max-session	3

Chapter 1 Telnet Commands

1.1 show telnet-server

[Function]

Use the command **show user** to show **telnet server** configuration.

[Command format]

show telnet-server

[Command Modes]

Privileged EXEC mode, Privileged user

[Executing Command Instruction]

Use the command **show telnet-server** to review current telnet server configuration.

[Example]

Raisecom# **show telnet-server**

Max session: 5

Accept port-list: 1-26

[Related commands]

Commands	Description
telnet-server accept port-list { <i>all</i> <i>portList</i> }	Set telnet ports on the switch.
telnet-server max-session <i>max-session-num</i>	Set maximal telnet connected number on the switch.
telnet-server close terminal-telnet <i>terminal-number</i>	Disable telnet connects to the switch.
telnet ip-address [port <i>port-number</i>]	telnet other switch or PC.

1.2 telnet

[Function]

telnet to remote device

[Command format]

telnet ip-address [**port** *port-number*]

[Parameter]

ip-address: ip address for remote device;

port-number: telnet port number.

[Command Modes]

Privileged EXEC; user diagnostic mode (for RC5xx series)

[Executing Command Instruction]

Only privileged users with priority higher than or equal 5 can use this command. Configure gateway first when the telnet switch is not in the same network segment with this switch.

[Explanation of command execution echo]

Connect failed!

Connection to host lost

[Example]

Logon telnet IP 10.1.2.3, the device provide telnet server port 555:

```
raisecom#telnet 10.1.2.3 port 555
```

[Related commands]

Commands	Description
telnet-server accept port-list { <i>all</i> <i>portList</i> }	Set telnet ports on the switch.
telnet-server max-session <i>max-session-num</i>	Set maximal telnet connected number on the switch.
telnet-server close terminal-telnet <i>terminal-number</i>	Disable telnet connects to the switch.
show telnet-server	Show telnet server configuration.

1.3 telnet-server close

[Function]

Shutdown connection of terminal telnet.

[Command format]

```
telnet-server close terminal-telnet terminal-number
```

[Parameter]

terminal-number: terminal telnet port number.

[Command Modes]

Global configuration mode

[Executing Command Instruction]

Use this command to shutdown connection of terminal telnet.

[Explanation of command execution echo]

Set successfully

Set unsuccessfully

[Example]

Shutdown telnet connection of terminal 1:

```
raisecom#telnet-server close terminal-telnet 1
```

[Related commands]

Commands	Description
telnet-server accept port-list { <i>all</i> <i>portList</i> }	Set telnet ports on the switch.
telnet-server max-session <i>max-session-num</i>	Set maximal telnet connected number on the switch.
telnet <i>ip-address</i> [port <i>port-number</i>]	Telnet to other switch or PC.
show telnet-server	Show telnet server configuration.

1.4 telnet-server max-session**[Function]**

Set maximal telnet connected number on the switch.

[Command format]

telnet-server max-session *max-session-num*

[Parameter]

max-session-num: maximal connection number of telnet.

[Default]

5 telnet can connect at maximum.

[Command Modes]

Global configuration mode

[Executing Command Instruction]

Use this command to set maximal telnet connected number on the switch.

[Explanation of command execution echo]

Set successfully

[Example]

Set telnet maximal connect number to be 3:

```
raisecom# telnet-server max-session 3
```

[Related commands]

Commands	Description
telnet-server accept port-list { <i>all</i> <i>portList</i> }	Set telnet ports on the switch.
telnet-server close terminal-telnet <i>terminal-number</i>	Disable telnet connects to the switch.
telnet <i>ip-address</i> [port <i>port-number</i>]	Telnet to other switch or PC.
show telnet-server	Show telnet server configuration.



北京瑞斯康达科技发展有限公司
RAISECOM TECHNOLOGY CO.,LTD.

Address: 2nd Floor, South Building of Rainbow Plaza, No.11 Shangdi Information Road,
Haidian District, Beijing Postcode: 100085 Tel: +86-10-82883305 Fax: +86-10-82883056
Email: export@raisecom.com <http://www.raisecom.com>