

www.raisecom.com

Commands of Storm-control-4



CONTENTS



Chapter 1	Commands of Storm-control	1
1.1	storm-control bps	1

Chapter 1 Commands of Storm-control

1.1 storm-control bps

[Function]

Set the storm control threshold for broadcast packet, multicast packet, and dlf, unit is kbps.

[Command Format]

storm-control bps *bit-number* [*schedule-list list-no*]

[Parameter]

bps: Broadcast control function threshold;

bit-number: the number of bit limitation which storm packet allow to pass each second;

schedule-list: Set the starting time, ending time and time interval of the schedule;

list-no: schedule list range is <0-99>.

[Default]

Bps of ISCOM2009/2109/2118 devices are 248kbps by default.

[Command Modes]

Global configuration mode; privileged user

[Executing Command Instruction]

Only the privileged user with priority 15 can use this command.

[Explanation of command execution echo]

Set successfully

Set unsuccessfully !

[Example]

Every second 500 Kbit can pass:

Raisecom(config)# **storm-control bps 500**

[Related commands]

Commands	Description
show storm-control	Show broadcast storm control setting for all or particular packet.



北京瑞斯康达科技发展有限公司
RAISECOM TECHNOLOGY CO.,LTD.

Address: 2nd Floor, South Building of Rainbow Plaza, No.11 Shangdi Information Road,
Haidian District, Beijing Postcode: 100085 Tel: +86-10-82883305 Fax: +86-10-82883056
Email: export@raisecom.com <http://www.raisecom.com>