


www.raisecom.com

Bandwidth Management Commands-4



CONTENTS



Chapter 1	Bandwidth Commands	1
1.1	show rate-limit port-list	1

Chapter 1 Bandwidth Commands

1.1 show rate-limit port-list

[Function]

Show bandwidth limit setting.

[Command Format]

show rate-limit port-list [{*port-list*}]

[Parameter]

rate-limit: rate limit;

port-list: physical port number;

port-list: physical port number, range: 1-26; use “,” and “-” to input multi ports.

[Command Modes]

Privileged EXEC, Privileged user

[Explanation of command execution echo]

I-Rate: Ingress Rate

I-Burst: Ingress Burst

E-Rate: Egress Rate

E-Burst: Egress Burst

Port I-Rate(Kbps) I-Burst(kBps) E-Rate(Kbps) E-Burst(kBps)

[Example]

Show bandwidth limit information:

Raisecom# **show rate-limit port-list**

[Related commands]

Commands	Description
rate-limit port-list	Show bandwidth limit of the port.
no rate-limit port-list	Delete bandwidth limit of the port.



北京瑞斯康达科技发展有限公司
RAISECOM TECHNOLOGY CO.,LTD.

Address: 2nd Floor, South Building of Rainbow Plaza, No.11 Shangdi Information Road,
Haidian District, Beijing Postcode: 100085 Tel: +86-10-82883305 Fax: +86-10-82883056
Email: export@raisecom.com <http://www.raisecom.com>