

www.raisecom.com

Commands of Storm-control-3



CONTENTS



Chapter 1 Commands of Storm-control ----- 1
1.1 storm-control pps -----1

Chapter 1 Commands of Storm-control

1.1 storm-control pps

[Function]

Set the storm control threshold for broadcast packet, multicast packet and dlf packet, unit: packet/second.

[Command Format]

storm-control *pps packets-number [schedule-list list-no]*

[Parameter]

- pps*: storm control threshold;
- packets-number*: storm packets permit passing every second, range is 0-262143;
- schedule-list*: Set the starting time, ending time and time interval of the schedule;
- list-no*: schedule list range is <0-99>.

[Default]

The default pps limitation is 1024

[Command Modes]

Global configuration mode; privileged user

[Executing Command Instruction]

Only the privileged user with priority 15 can use this command.

[Explanation of command execution echo]

- Set successfully*
- Set unsuccessfully !*

[Example]

Set the storm control pps to be 5000:
 Raisecom(config)# **storm-control** *pps 5000*

[Related commands]

Commands	Description
show storm-control	Show broadcast storm control setting for all or particular packet.



北京瑞斯康达科技发展有限公司
RAISECOM TECHNOLOGY CO.,LTD.

Address: 2nd Floor, South Building of Rainbow Plaza, No.11 Shangdi Information Road,
Haidian District, Beijing Postcode: 100085 Tel: +86-10-82883305 Fax: +86-10-82883056
Email: export@raisecom.com <http://www.raisecom.com>