

www.raisecom.com

MST Function Commands-1



CONTENTS



Chapter 1	MST Function Commands	1
1.1	debug	1

Chapter 1 MST Function Commands

1.1 debug

[Function]

Use **debug** command to turn on modular debugging switch, **no** command to turn the switch off.

[Command Format]

[**no**] **debug** (*all / system / ospf / rip / gvrp / igmp-snooping / mvr / cli / driver / dhcp / snmp / stp / lacp / rcmp / rndp / rtdp / radius / dot1x / qos / rmon / sntp / telnet / arp / ip / config*)

[Parameter]

all: debug all functions

arp: arp debug

cli: cli debug

config: system config information

dhcp: dhcp debug

dot1x: dot1x debug

driver: driver debug

gvrp: gvrp debug

igmp-snooping: igmp-snooping debug

ip: ip debug

lacp: lacp debug

ospf: ospf debug

qos: qos debug

radius: radius debug

rcmp: rcmp debug

rip: rip debug

rmon: rmon debug

rndp: rndp debug

rtdp: rtdp debug

snmp: snmp debug

sntp: sntp debug

stp: stp debug

system: system debug

telnet: telnet debug

[Default]

Config module is enabled

System module is enabled

Others debug functions are disabled

[Command Modes]

Privileged EXEC, Privileged user

[Executing Command Instruction]

Use this command to enable some or all module **debug** functions. **All** indicates all modules, **config** module indicates it can be record in flash file system.

[Example]

Raisecom#**debug all**

[Related commands]

Commands	Description
logging	Configure system log



北京瑞斯康达科技发展有限公司
RAISECOM TECHNOLOGY CO.,LTD.

Address: 2nd Floor, South Building of Rainbow Plaza, No.11 Shangdi Information Road,
Haidian District, Beijing Postcode: 100085 Tel: +86-10-82883305 Fax: +86-10-82883056
Email: export@raisecom.com <http://www.raisecom.com>