


www.raisecom.com

Commands of Storm-control-2



CONTENTS



- Chapter 1 Commands of Storm-control ----- 1
- 1.1 storm-control-----1
- 1.2 show storm-control ----- 错误! 未定义书签。

Chapter 1 Commands of Storm-control

1.1 storm-control

[Function]

Enable or disable port storm control function.

[Command Format]

storm-control {multicast | dlf | all} {enable | disable} [schedule-list list-no]

[Parameter]

- multicast*: multicast packet;
- dlf*: target searching failure packet;
- all*: broadcast packet, multicast packet and dlf;
- enable*: enable storm control function;
- disable*: disable storm control function;
- schedule-list*: Set the starting time, ending time and time interval of the schedule;
- list-no*: schedule list range is <0-99>.

[Default]

storm control function enable

[Command Modes]

Global configuration mode; privileged user

[Executing Command Instruction]

Only the privileged user with priority 15 can use this command.

[Explanation of command execution echo]

- Set successfully*
- Set unsuccessfully !*

[Example]

- Enable broadcast storm-control function:
Raisecom(config)# **storm-control** multicast enable
- Disable all the storm-control function:
Raisecom(config)# **storm-control** all disable

[Related commands]

Commands	Description
----------	-------------

show storm-control Show storm control function configuration
for all packets or one type of packet.



北京瑞斯康达科技发展有限公司
RAISECOM TECHNOLOGY CO.,LTD.

Address: 2nd Floor, South Building of Rainbow Plaza, No.11 Shangdi Information Road,
Haidian District, Beijing Postcode: 100085 Tel: +86-10-82883305 Fax: +86-10-82883056
Email: export@raisecom.com <http://www.raisecom.com>