

[www.raisecom.com](http://www.raisecom.com)

## **Trunk Group Commands-1**



# CONTENTS



- Chapter 1 Trunk Group Commands----- 1**
- 1.1 show trunk-----1**
- 1.2 trunk-----1**
- 1.3 trunk group-----2**

# Chapter 1 Trunk Group Commands

## 1.1 show trunk

### [Function]

Show trunk information, trunk mode and member port of current trunk group and current enabled member port.

### [Command Format]

**show trunk**

### [Command Modes]

Privileged EXEC, Privileged user

### [Executing Command Instruction]

This command is used to display the load-sharing mode of all aggregated links, ticket algorithm using mac address, all current aggregation group, group members and current effective member port. The current effective member port is the group member that has “UP” status.

### [Explanation of command execution echo]

*Trunk: Enable*

*Loading sharing mode: SXORDMAC*

*Loading sharing ticket algorithm: --*

*Trunk Group                  Member Ports                  Efficient Ports*

### [Example]

Display current trunk related information:

Raisecom# **show trunk**

### [Related commands]

Commands	Description
<b>trunk</b>	Enable/disable trunk function.
<b>trunk-group</b>	Create an aggregation group.
<b>trunk-loading-sharing mode</b>	Set the load-sharing mode of all aggregated ports

## 1.2 trunk

### [Function]

Enable or disable trunk function.

### [Command Format]

**trunk** {*enable/disable*}

**[Parameter]**

*enable*: enable trunk function

*disable*: disable trunk function

**[Default]**

enable

**[Command Modes]**

Global configuration mode; Privileged user.

**[Executing Command Instruction]**

Use this command to enable or disable trunk function.

**[Explanation of command execution echo]**

*Set success*

*Set unsuccessfully !*

**[Example]**

Enable trunk function for the link:

Raisecom(config)# **trunk enable**

Disable trunk function for the link:

Raisecom(config)# **trunk disable**

**[Related commands]**

Commands	Description
<b>show trunk</b>	Show trunk status, trunk load-sharing mode, all the trunk members of the trunk group and all the current enabled port member.

## 1.3 trunk group

**[Function]**

Add a trunk group, **no** command is used to delete the operation.

**[Command Format]**

**trunk group** *trunk-group-id portlist*

**no trunk group** *trunk -group-id*

**[Parameter]**

*trunk-group-id*: trunk group ID, range is 1—6.

*portlist*: port number for the group, format can be 1-3, 5 etc. 8 ports as the maximum.

**[Command Modes]**

Global configuration mode, privileged user

**[Executing Command Instruction]**

Use this command to create a link trunk. Combine appointed *portlist* aggregation to a single aggregation port. Each aggregation port includes 8 ports with the same speed as the maximum.

Use **no trunk group** *trunk-group-id* to delete appointed aggregation.

#### [Explanation of command execution echo]

*Set successfully*

*Set unsuccessfully !*

*Permit 8 members at most!*

*Some member ports are overlapped with those of other trunk group!*

*Trunk group 3 is not exist!*

#### [Example]

Create aggregation group 3, including prt 1, 4, 5, 6, 8:

```
Raisecom(config)#trunk group 3 1,4-6,8
```

Delete aggregation group 3:

```
Raisecom(config)#no trunk group 3
```

#### [Related commands]

Commands	Description
<b>show trunk</b>	Show trunk status, trunk load-sharing mode, all the trunk members of the trunk group and all the currently enabled port member.



**北京瑞斯康达科技发展有限公司**  
**RAISECOM TECHNOLOGY CO.,LTD.**

Address: 2<sup>nd</sup> Floor, South Building of Rainbow Plaza, No.11 Shangdi Information Road,  
Haidian District, Beijing Postcode: 100085 Tel: +86-10-82883305 Fax: +86-10-82883056  
Email: [export@raisecom.com](mailto:export@raisecom.com) <http://www.raisecom.com>