www.raisecom.com

QoS Function Commands-3

CONTENTS

Chapter 1 QoS Function Commands ---------- 1
1.1 queue strict-priority----------1

Chapter 1 QoS Function Commands

1.1 queue strict-priority

[Function]

Set the queueing mode of the port to strict priority mode.

[Command format]

queue strict-priority

[Default]

Default queueing mode is strict priority (SP).

[Command Modes]

Global configuration mode; privileged user.

[Executing Command Instruction]

Set the queueing mode to strict priority.

[Explanation of command execution echo]

Set the strict priority mode successfully.

Set the strict priority mode unsuccessfully.

[Example]

Raisecom(config)# **queue strict-priority**

[Related commands]

Commands	Description
show mls qos queueing	Show queue information.

北京瑞斯康达科技发展有限公司
RAISECOM TECHNOLOGY CO.,LTD.

Address: 2nd Floor, South Building of Rainbow Plaza, No.11 Shangdi Information Road, Haidian District, Beijing Postcode: 100085 Tel: +86-10-82883305 Fax: +86-10-82883056
Email: export@raisecom.com http://www.raisecom.com