

www.raisecom.com

Commands Line Usage Configuration

Legal Notices

Raisecom Technology Co., Ltd makes no warranty of any kind with regard to this manual, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. **Raisecom Technology Co., Ltd** shall not be held liable for errors contained herein or direct, indirect, special, incidental or consequential damages in connection with the furnishing, performance, or use of this material.

Warranty.

A copy of the specific warranty terms applicable to your Raisecom product and replacement parts can be obtained from Service Office.

Restricted Rights Legend.

All rights are reserved. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of **Raisecom Technology Co., Ltd.** The information contained in this document is subject to change without notice.

Copyright Notices.

Copyright ©2006 Raisecom. All rights reserved.

No part of this publication may be excerpted, reproduced, translated or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in Writing from **Raisecom Technology Co., Ltd.**

Trademark Notices

RAISECOM is the trademark of Raisecom Technology Co., Ltd.

Java™ is a U.S. trademark of Sun Microsystems, Inc.

Microsoft® is a U.S. registered trademark of Microsoft Corporation.

Windows NT® is a U.S. registered trademark of Microsoft Corporation.

Windows® 2000 is a U.S. registered trademark of Microsoft Corporation.

Windows® XP is a U.S. registered trademark of Microsoft Corporation.

Windows® and MS Windows® are U.S. registered trademarks of Microsoft Corporation.

Contact Information

Technical Assistance Center

The Raisecom TAC is available to all customers who need technical assistance with a Raisecom product, technology, or, solution. You can communicate with us through the following methods:

Add: 1120, Haitai Tower, 229 Fourth North Loop Middle Road, Haidian District, Beijing 100083

Tel: +86-10-82884499 Ext.878 (International Department)

Fax: +86-10-82885200, +86-10-82884411

World Wide Web

You can access the most current Raisecom product information on the World Wide Web at the following URL:

<http://www.raisecom.com>

Feedback

Comments and questions about how the NView iEMS system software works are welcomed. Please review the FAQ in the related manual, and if your question is not covered, send email by using the following web page:

<http://www.raisecom.com/en/xcontactus/contactus.htm>.

If you have comments on the NView iEMS specification, instead of the web page above, please send comments to:

export@raisecom.com

We hope to hear from you!

CONTENTS

Chapter 2 Commands Line Usage	5
2.1 introduction to commands line	5
2.2 commands line usage configuration	5
2.2.1 commands line mode configuration	5
2.2.3 Getting Help	8
2.2.3 Using Editing Features	8
2.2.4 Command-line History	9
2.2.5 The command-line Error	9

Chapter 2 Commands Line Usage

2.1 introduction to commands line

Commands Line is the channel for the communication between subscribers and switches. In the commands lines, subscribers are able to monitor, control and manage the switches through configuring the corresponding commands. For better convenience, subscribers can edit shortcuts to use the commands, by the same time subscribers can examine the used commands through transferring the history. The commands line mode confines the way different subscribers use commands lines, where various commands line modes are offered. Subscribers can make certain configuration only in the corresponding mode.

2.2 commands line usage configuration

2.2.1 commands line mode configuration

模式	Mode description	Access	Prompt	Out
Universal subscriber mode	Subscriber is allowed to configure the basic information and the parameter shown on the switch.	Login the switch and enter the user's name and password.	Raisecom>	Exit Withdraw from the current mode.
Subscriber privileges mode	Subscriber is allowed to configure the basic information of the switch, like system time and the name of the switch, except the operation information.	From universal subscriber mode, type enable and password.	Raisecom#	Exit Withdraw from the current mode.
Global configuration mode	Subscriber is allowed to configure all the operation parameters.	From subscriber privilege mode, type config	Raisecom(config)#	Exit Withdraw from the current mode.

Physical layer interface configuration mode	Subscriber is allowed to configure the Ethernet physical interface of the switch.	From global configuration mode,type interface port portid.	Raisecom(config-port)#	Exit Withdraw from the current mode.
Physical layer interface bulk configuration mode	Subscriber is allowed to range configure the parameter of the switch's Ethernet physical interface.	From global mode,type interface port portid.	Raisecom(config-range)#	Exit Withdraw from the current mode.
Three-tier interface configuration mode	Subscriber is allowed to configure the switch's three-tier Ethernet interface.	From global mode ,type interface port ip id.	Raisecom(config-ip)#	Exit Withdraw from the current mode.
VLAN configuration mode	Subscriber is allowed to configure the VLAN operation parameters.	Enter vlan	Raisecom(config-vlan) #	Exit Withdraw from the current mode.
Class Map configuration mode	Subscriber is allowed to configure the given data flow.	From global configuration mode, type class-map class-map-name [match-all match-any] command.	Raisecom(config-cmap))#	Exit Withdraw from the current mode.
Policy Map configuration mode	Subscriber is allowed to classify and package the data flow defined by class-map.	From global configuration mode, type policy-map policy-map-name command.	Raisecom(config-pmap))#	Exit Withdraw from the current mode.

Traffic classification configuration mode	Subscriber is allowed to configure the action of the date flow.	From policy map exec mode, type class-map class-name command.	Raisecom(config-pmap -c)#	Exit Withdraw from the current mode.
The cluster configuration mode	Subscriber is allowed to configure the cluster.	From global configuration mode, type cluster command.	Raisecom(config-cluste r)#	Exit Withdraw from the current mode.
Access control list mapping table configuration mode	Subscriber is allowed to configure the access control list mapping table.	From global configuration mode, type access-list-map <0-399> {permit deny} command.	Raisecom(config-aclma p)#	Exit Withdraw from the current mode.
Subscriber network mode	Subscriber is allowed to configure three-tier network setting,show the users' network information and network tools.	Form global configuration mode,type user-network diagnostics.	Raisecom(config-usrnet)#	Exit Withdraw from the current mode.
RIP configuration mode	Subscriber is allowed to configure RIP.	Forom global configuration mode, type router rip.	Raisecom(config-router -rip)#	Exit Withdraw from the current mode.
OSPF configuration mode	Subscriber is allowed to configure OSPF.	From global configuriom mode, type router ospf.	Raisecom(config-router -ospf)#	Exit Withdraw from the current mode.

2.2.3 Getting Help

Command	Functional description
help	Get a short system help both in English and in Chinese.
<i>abbreviated-command-entry?</i>	Get a list for all the available commands that match a particular string prefix (<i>abbreviated-command-entry</i>). For example: ISCOM> en? english enable
<i>abbreviated-command-entry</i> <Tab>	Makeup an incomplete command. For example. Raisecom# show ser <Tab> Raisecom# show service
?	List all the commands under this mode. For example Raisecom#?
<i>command?</i>	List all the key words and options for particular command with a short help information for it. Raisecom# show ?
<i>command keyword ?</i>	List the key words corresponding command For example Raisecom(config)# ip ? Ip IP setting ip-access-list Define IP access control list

2.2.3 Using Editing Features

up arrow:	last entered command
down arrow:	next entered command
left arrow:	move a character left
right arrow:	move a character right
backspace:	delete a character in front of the cursor
Ctrl+d:	delete a character at the cursor
Ctrl+a:	move the cursor to the beginning of the command line
Ctrl+e:	move the cursor to the end of the command line
Ctrl+k:	delete all the characters to the right the cursor
Ctrl+w:	delete all the characters to the left of the cursor
Ctrl+u:	delete the row all

Ctrl+z: exit from other modes to privileged mode

2.2.4 Command-line History

The switch records the latest 20 commands in the cache by default. User can use the following command to set the number of history commands that will be recorded.:

Raisecom>terminal history <0-20>

Use **history** to show the history command.

2.2.5 The command-line Error

Error	Description	Getting help
Unknowncommand or in accurate For example Raisecom#sh co %" co " Unknown command.	Review the command needed.	
The command is not confirmed: For example Raisecom#sh r %" r " Unconfirmed command	Input the order that can not be recognized by the switch from the commands.	Add ? for annotation and command. For example: Raisecom# sh r rate-limit: Rate control rmon: RemoteNetwork Monitoring (RMON) configuration rndp: RNDP configuration rtdp: RTDP configuration running-config: Running system configuration information
Command incomplete For example Raisecom#show % " show " Incomplete command.	The switch can not recognize the operation form the command, command that can be recognized is needed.	Add ? for command and annotation. For example: Raisecom# sh r rate-limit: Rate control rmon: RemoteNetwork Monitoring (RMON) configuration

		<div>rndp: RNDP configuration</div> <div>rtdp: RTDP configuration</div> <div>running-config:</div> <div>Running system configuration information</div>
--	--	--

地址：北京市海淀区北四环中路 229 号海泰大厦 617/619 室 邮编：100083 电话：(8610)-82884499
传真：(8610)-82885200 Http://www.raisecom.com 技术支持：help@raisecom.com
销售热线：86-10-82884499 转 600 技术咨询热线：(8610)-82883110 82884499 转 87